POPCORN MACHINE INSTRUCTIONS

- 1. Plug machine into a 110V outlet
- 2. Turn on both switches (heat and motor)
 - For first batch, let kettle pre-heat for approx. 4 minutes
- 3. Pour oil contents into kettle
 - If oil is hardened, let oil melt
- 4. Pour popcorn kernels into kettle and close lid
- 5. Once popcorn pops, it will overflow and fall to bottom of machine
- 6. Listen for popping sound to slow down
- 7. Once popping stops, dump kettle immediately to avoid burning
- 8. To continue popping consecutively, repeat steps 3-7.
- ~ Always keep both kettle switches off when not using machine!
- ~ If you have burned corn or excessive smoke, turn kettle heat off for a few minutes

Cleaning

- 1. Empty any leftover popcorn/kernels from machine
- 2. Wipe down glass inside with warm soapy water and dry
- 3. Empty kettle and wipe inside with warm soapy water and dry DO NOT SUBMERSE KETTLE IN WATER DAMAGE WILL OCCUR TO HEATING ELEMENT AND MOTOR!